

WONDERWARE (AVEVA) Aveva InTouch Lisanslama



BAUTEK BİLGİ TEKNOLOJİLERİ

DİJİTAL DÖNÜŞÜM YOLCULUĞUNUZDA PUSULANIZ.

Dijital dönüşüm yolculuğunuzun neresindesiniz? Nereden başlayacağınızı biliyor musunuz? Kapsamlı bir dijital dönüşüm stratejisi, işletmeniz için sürdürülebilir bir geleceğe giden yol haritanızı oluşturmaktadır.

BAUTEK olarak operasyonel mükemmelliğe yönelik sağladığımız dijital çözümlerimizle operasyonlarınızı daha sürdürülebilir, daha etkin, daha verimli hale getirebilir, kaynak kullanımını düşürerek minimize edebilir ve kazanç miktarını arttırarak gelir maksimizasyonunu sağlayabiliriz.

Türkiye’de ve dünyada öncü markaların tercihi olan çözümlerimizle operasyonel süreçlerden yönetsel süreçlere tüm faaliyetlerinizi zaman ve mekân sınırlaması olmadan **7/24** yönetebilirsiniz.

Operasyonel Mükemmelliğe yönelik dijitalizasyon çözümlerimiz;

- SCADA Çözümleri,
- Endüstriyel IT/OT Entegrasyon Platform,
- MES - Üretim Yönetim Sistemi Çözümleri (OEE Performans | Operasyon | Kalite)
- Endüstriyel Veri Toplama (Historian Server) ve Raporlama,
- Üretim Veri Toplama ve İzlenebilirlik,
- Ekipman Varlık ve Kestirimci Bakım Yönetimi,
- Enerji İzleme ve Enerji Performans Yönetimi,
- Saha Mobil Prosedür ve Dijital Prosedür Yönetim,
- Operatör Performans Destek ve Dijital Kaizen,
- İş Akış Yönetim Sistemi Çözümleri,
- OT PLC-SCADA Uygulama Yedek ve Değişim Yönetim,
- Reçete ve Batch Yönetim,
- Alarm Yönetim ve OPC Server (Tunneler),
- ERP Entegrasyon Çözümleri ve daha fazlası...

Ayrıca sektörlere özel, işletmelerin ihtiyaçlarına yönelik sunduğumuz en etkili endüstriyel yazılım çözümlerimiz hakkında ayrıntılı bilgi almak, teknik döküman ve demo uygulamaları incelemek için bizimle iletişime geçebilirsiniz.

Quick Guide to Activated Licensing

Version 1.0 July 2019

- This is a quick guide; consult the Schneider Electric Licensing Guide for more information
- To manage licensing, you must be a member of OS group SELicMgr.
- The machine running License Manager must have firewall port 55555 open (default; it is changeable).
- You install AVEVA Enterprise License Manager during product installation

It is most common to install the License Manager on the same server, although not required.

- You can have a centralized license server that manages your repository of licenses (Server model).

Or a license server on each individual machine managing only its own licenses (Distributed model).

The steps below are the same for either model.

1. Gather your XML file(s). These are emailed to you when you purchase the software.

2. Open License Manager.

Start->AVEVA->AVEVA Enterprise License Manager. It will use your default web browser.

3. Log in (using a login that is a member of the SELicMgr OS group.

4. One License Server will be shown (the one you installed on this machine), with 0 licenses running.

5. Are you connected to the internet?

YES - use Online Activation, which is the default.

NO – use Offline Activation:

- Click the Server Menu button:
- Select Activation settings, then select Offline Activation
- Select the Server Menu button again, and select Servers, to go back.

6. Click the large rectangle denoting your license server. This brings up your license summary window.

7. Click the Plus button to Add License.

8. Navigate to your XML file, click Open. It will load your license components into this window:

9. Select which products you wish this license server to manage.

- If using the server model, this likely will be all of them.
- If distributed model, pick only the product(s) that will run on this local machine.

10. Click the Activate button in the lower right.

Online Activation

11. If Online, the license will activate automatically and your license component will show status as Activated.

Offline Activation

12. If Offline, you will see a yellow Offline Activation button appear in the upper right.

13. Pull down the selector arrow on the yellow button to display the Request/Receive buttons.

14. Select the Request Activation button. This will create a 'Send' file, asking you to save it to a location of your choice.

15. Copy that file to a machine connected to the internet. Go to this website:

<http://licenseactivation.wonderware.com/>

16. Using the wizard on the website, upload this 'Send' file.

17. Once completed, the site will generate a complimentary 'Receive' file and ask where you want it saved.

18. Copy this 'Receive' file to your target machine (or leave it on a connected thumbdrive, etc.).

19. Return to the License Manager, to the same License Summary page.

20. Again, pull down the selector arrow on the yellow button in the upper right.

21. This time click the Receive Activation button.

22. Navigate to your 'Receive' file and select Activate.

23. Your license components now show status as Activated.

IMPORTANT!

If you ever decommission this machine, delete the VM, etc., be sure to Deactivate the license first, or the license will be locked to a non-existent machine. The process is the same, just choose Deactivate.



“Operasyonel Mükemmellik”
mottosuyla sunduğumuz yazılım
çözümleri ile yatırımlarınızdan
maksimum getiriye sağlayacak
optimizasyon fırsatlarını keşfetmeye
hemen başlayın.

www.bautek-tr.com

